



Gedae Compiler User's Manual

June 22, 2010

Address: Gedae, Inc.
1247 N Church St, STE 5
Moorestown, NJ 08057
Telephone: (856) 231-4458
FAX: (856) 231-1403
Internet: www.gedae.com

Table of Contents

1	Introduction.....	4
2	Group Control Dialog	5
3	Partitioning.....	6
4	Mapping	8
	Embedded Configuration File Description	8
	Setting Trace Buffer Size and Memory Type	9
	Setting Processor Parameters	9
	Setting the Target Host	10
5	Transfer Method Control	11
	Setting the Transfer Method	11
	Setting Transfer Method Parameters	11
6	Firing Granularity	13
	Setting the Granularity	13
	Subscheduling	14
7	Multibuffering Unmapped Memory Transfers	15
8	Priority Table	22
9	Memory Packing Control.....	23
10	Setting Dynamic Queue Properties.....	24
11	Setting Static Schedule Thread Properties.....	25
12	Launch Package Generation Control	27
	Parameters and Queues	27
	Executables	28
	Launch Package	28


1 Introduction

This document describes various features of the Gedae graph compiler. It includes descriptions of various user controls over compilation, primarily the Group Control Dialogs. It also describes how Gedae implements an application in response to user settings.

The primary way of entering compiler settings is through tables. The tables have a few basic properties. Any field with a white background can be modified. Fields with a grey background cannot. A field that ends with an asterisk (*) indicates that the field has been modified by the user. Text displayed in red indicates the value is derived from another user setting. Most tables are hierarchical. The name column is grouped by schedule or graph hierarchy that can be collapsed or expanded by double clicking or through the Edit menu. Most tables have menu items in the Edit menu for setting all items to the same value or for resetting all values to their default value. Most tables have a Help menu item to explain basic functionality.


2 Group Control Dialog

The Group Control Dialog provides a central interface for the viewing and setting of compiler parameters. A Geda flow graph is divided into groups by the use of host boundaries, such as the boxes in embeddable/stream/host. To open the Group Control dialog, right click on a box whose group you want to control and select “Group Control...” or use the menu item “Options->Group Control...” The Group Control Dialog includes several toggles and menus to provide high level settings along with a series of buttons for opening tables to provide more fine level settings.




3 Partitioning

The Partition Table allows the user to group boxes into partitions. It is launched using the Partition Table button on the Group Control. Partitions can then be mapped to physical processors in the Map Partition Table. Users group boxes by assigning boxes to partition names. These partition names are arbitrary alphanumeric strings. Each box assigned to the same name is in the same partition.



The Partition Table lists all the boxes in the group in the Name column. The list is hierarchical and can be expanded or collapsed by double clicking on each name. Assigning a parent box to a partition causes all the children and other descendent boxes to also be assigned to that partition.

If families are used in creating the flow graph, then equations can be used to set family members to different partitions. The equations consist of integers, quoted strings and variables. The variables represent the family dimension and are \$1, \$2, etc. The value of these variables can be modified via integer arithmetic in the equation, for example, (\$1+100), supporting the operators +, -, *, /, and % (modulus). The result of this arithmetic can be concatenated with quoted strings using the + operator. Parentheses can be used to separate the integer arithmetic from the string concatenation.




The image shows a window titled "Group 2 Partition Table" with a menu bar containing "File", "Edit", "View", and "Options". Below the menu bar is a table with two columns: "Name" and "Partition". The table contains eight rows of data, each with a green background. The rows are grouped into two sets of four. The first set consists of "range_p" entries with indices [0] through [3], and the second set consists of "azimuth_p" entries with indices [0] through [3]. Each entry in the "Partition" column follows the format "p0="p"+\$1", where the index from the "Name" column is used as the subscript for 'p'.

Name	Partition
[0]range_p	p0="p"+\$1
[1]range_p	p1="p"+\$1
[2]range_p	p2="p"+\$1
[3]range_p	p3="p"+\$1
[0]azimuth_p	p0="p"+\$1
[1]azimuth_p	p1="p"+\$1
[2]azimuth_p	p2="p"+\$1
[3]azimuth_p	p3="p"+\$1

4 Mapping


The Map Partition Table allows for mapping partitions to physical processors. It also allows for setting processor-specific parameters such as trace collection and architecture-specific settings. The Map Partition Table is launched by pressing the Map Partition Table button in the Group Control.

The partitions created in the Partition Table are listed in the Name column of the Map Partition Table. Partitions are mapped to processors by setting the ProcNum values for each partition. The ProcNum values are defined in the embedded configuration. Each physical processor in the system can have zero, one, or more than one partitions mapped to it.



Name	CP	ProcNum	System Name	Trace Size	Trace MemType	Params
0		0 *	ent	10000 *	default	
1		1 *	ent	10000 *	default	
2		2 *	ent	10000 *	default	
3		3 *	ent	10000 *	default	

Similar to the partition table, equations can be used to map a set of partitions to a set of processors. The \$1, \$2, etc. variable syntax is used to reference the 1st, 2nd, etc. integer in the partition name. Integer arithmetic can be used in the ProcNum equations to translate the integers inside the partition names into processor numbers.



Name	CP	ProcNum	System Name	Trace Size	Trace MemType	Params
p0		0=\$1	ent	10000	default	
p1		1=\$1	ent	10000	default	
p2		2=\$1	ent	10000	default	
p3		3=\$1	ent	10000	default	


The mapping of partitions to physical processors is not complete until the Run on Target button in the Group Control Dialog is changed to on. If the graph is run with this button off, then the partitions will all run on the host processor, and the inserted send and receive boxes will simply copy data between buffers.

Embedded Configuration File Description

The embedded configuration can be viewed using the Hardware Configuration Viewer. The Hardware Configuration Viewer is launched by pressing the Configuration Viewer

button in the Group Control. The viewer lists each physical processor in the system. It has four columns

- Name: the integer processor number.
- Physical Proc: the hostname (or I.P. address) of the processor where “local” indicates the same processor as the development environment.
- System: the name of the board support package partitions mapped to this processor will use.
- Type: the processor type.



The screenshot shows a window titled "Hardware Configuration Viewer" with a menu bar containing "File", "Edit", "View", and "Options". Below the menu bar is a table with four columns: "Name", "Physical Proc", "System", and "Type". The table contains eight rows of data, indexed from 0 to 7. Each row shows a processor name, the word "local" in the Physical Proc column, "ent" in the System column, and "nt" in the Type column.

Name	Physical Proc	System	Type
0	local	ent	nt
1	local	ent	nt
2	local	ent	nt
3	local	ent	nt
4	local	ent	nt
5	local	ent	nt
6	local	ent	nt
7	local	ent	nt

Setting Trace Buffer Size and Memory Type

The Map Partition Table can also be used to customize trace collection. Trace events are shown in the Trace Table. The Map Partition Table is used to control how much space is available for trace events and what memory partition those events are stored in. Trace collection uses a circular buffer; the size of the buffer correlates to the duration of time shown in the table. The Trace Size column is used to specify the size of the buffer. The values are entered in number of bytes. Equations can be used to set the size for all partitions. The Trace MemType column is used to store the events in a specific memory bank or buffer. For example, on the Cell/B.E. processor, the user may wish to store events in system memory instead of in SPE local storage to save local storage for more vital program data.

Setting Processor Parameters

Each board support package has several processor-specific parameters available. These parameters can be entered into the Params column of the Map Partition Table. To find out what parameters are available for the current hardware, select Options->View Settable Params...

Setting the Target Host

The Target Host area of the Group Control can be used to specify a host for the application other than the development host. This target host can be any processor in the embedded configuration, simply press the “Set” button in the group control and enter the processor ID number of the selected physical processor. When it is selected, the processor numbers in the Mapping Table now reference the embedded configuration file named after the target host. For example, if the development host is a Linux x86 workstation and processor 100 is a Power Processing Element (PPE) of a Cell Broadband Engine processor on the same network as the x86, one should set the target host to 100 to gain access to the SPEs (Synergistic Processing Elements) underneath the PPE. Consult the *Embedded Configuration Manual* for more information on setting up hierarchical embedded configuration files.

The CP column of the Map Partition Table is used to specify which processor runs the command program. Selecting this option forces the group’s target host to be set to the development host. Command programs generated while using the CP column setting require that each generated executable be explicitly started without help from the command program.

5 Transfer Method Control

The Transfer Table is used to set communication properties for any processor to processor connection and is launched by pressing the Transfer Table button in the Group Control. If two kernels are connected by an arc and mapped to different processors, then a transfer is automatically inserted between the two kernels to send the data. Each of these transfers is listed in the table. A board support package may provide multiple transfer methods for the target hardware, and each transfer method may have parameters that can be set to optimize the transfer's performance.

The table lists the transfers according to the name of the destination of the transfer, that is, the input to the kernel that receives the data. The table also lists an Id number for the transfer. This Id number is used in the name of the send and receive kernels inserted into the application (for example, "send_13"), and the names are useful for tracking transfers in the Trace Table and other debugging dialogs. The table also lists the source and destination processor id number.

Setting the Transfer Method

The transfer method is selected in the Xfer Type column. There are two main types of transfers – streaming transfers and DMA transfers (direct memory access).

Setting Transfer Method Parameters

Streaming transfers, such as sockets, have an NBsize parameter. The NBsize specifies the size of the buffer and, if set high enough, can ensure the transfer is nonblocking. The column can be set to an integer number of bytes or to the string "nb" to allow Gedae to determine the size of the buffer required to make the transfer nonblocking.

DMA transfers allow both the sends and receives to be multibuffered. The Send Bufs and Recv Bufs columns allow the user to specify the number of buffers to use in the multibuffering scheme for each transfer.

Additional parameters may be available for the target system and can be set in the Xfer Params column.

Group 2 Transfer Table

File Edit View Options Help

Name	Id	Source	Dest	Xfer Type	NBsize	Send Bufs	Recv Bufs	Xfer Params
[0]azimuth_p								
vx_mux<[1]in	7	1	0	stream_socket	8192 *			
vx_mux<[2]in	4	2	0	stream_socket	8192 *			
vx_mux<[3]in	1	3	0	stream_socket	8192 *			
[1]azimuth_p								
vx_mux<[0]in	10	0	1	stream_socket	8192 *			
vx_mux<[2]in	5	2	1	stream_socket	8192 *			
vx_mux<[3]in	2	3	1	stream_socket	8192 *			
[2]azimuth_p								
vx_mux<[0]in	11	0	2	stream_socket	8192 *			
vx_mux<[1]in	8	1	2	stream_socket	8192 *			
vx_mux<[3]in	3	3	2	stream_socket	8192 *			
[3]azimuth_p								
vx_mux<[0]in	12	0	3	stream_socket	8192 *			
vx_mux<[1]in	9	1	3	stream_socket	8192 *			
vx_mux<[2]in	6	2	3	stream_socket	8192 *			

6 Firing Granularity

Granularity can be either increased or decreased via the Fire Table. The goal is to set the granularity such that fast memory (cache or other local storage) is best utilized. It is best to process at large granularities, but not so large that the data does not fit into fast memory.

The Name column lists the schedules in the graph. Underneath the schedules, it enumerates sets of boxes that must have the same granularity. The boxes in the set can be viewed by double clicking on the integer label.

Setting the Granularity

The Gran column is the only settable column. The Bytes column shows an estimate of how many bytes are required from memory to execute at granularity 1. The Bytes*Gran column shows how many bytes are required from memory to execute at the current Gran settings. The Gran column should be set such that Bytes*Gran makes good use of fast memory.




Name	Gran	Subsched	Exec Gran	Bytes	Bytes*Gran	Default G	Total G	Boxes
Schedule 1	1			393216	393216	1	1	8
1	16			24576	393216	16	16	20
2	64			1536	98304	64	64	4
3	64			1536	98304	64	64	4
4	64			1536	98304	64	64	4
5	64			1536	98304	64	64	4

The Gran field can be set to change the Bytes*Gran field in one of four ways:

1. Edit->Reset All Grans: Set all granularities to the Total G (that is, the total granularity of the boxes in the set, or the number of times the boxes must fire to complete one cycle of the schedule it is part of).
2. Edit->Set Limit: Set all granularities in an attempt to keep Bytes*Gran less than the limit entered. If this limit is less than the Bytes value, then the schedules are automatically subscheduled in order to reduce memory usage. If this limit is greater than the Bytes value, then the schedules' granularities are increased as much as possible while staying within the limit. Maximum subscheduling can be achieved by setting the limit to 0.
3. Options->Set Gran: Sets the Gran field of the selected set or schedule to the value entered.
4. Directly typing values into the Gran column in the table.

Subscheduling

Subscheduling (or strip-mining) allows the granularity to be decreased below the natural granularity. A common example of a situation where it is advantageous to apply subscheduling is the row-wise processing of a matrix. If a stream of R row vectors is extracted from a matrix, processed individually, and then inserted back into the matrix, then subscheduling can be applied to process one row at a time instead of the full R vectors.




7 Multibuffering Unmapped Memory Transfers


Mapped memory is normal processor memory that can be accessed by dereferencing pointers to the memory. Unmapped memory is memory that can only be accessed via a set of functions that move data between unmapped and mapped memory. Some BSPs provide the ability to allocate large memory blocks that are unmapped. For example, the Gedae SPU BSP that runs on Cell/B.E SPU processors allows memory areas to be declared unmapped. The Gedae functions supporting the transfer of data between unmapped and mapped memory are defined in the *Gedae Primitive Function Reference Manual*. These functions include both blocking and nonblocking versions of functions for moving data between mapped and unmapped memory. Variants of these functions are also available for moving data between subtiles in unmapped memory into a contiguous matrix in mapped memory.

Gedae allows users to declare that primitive inputs or outputs are in unmapped memory (see the *Gedae Primitive Programmers Manual*). Zero-copy data-reorg primitives are primitives whose inputs are in place with their outputs and do not modify the values of the data, but merely reinterpret it. If the input or output of a zero-copy primitive is connected to an unmapped memory, then the other input or output and its in place counterpart are both declared unmapped. Thus starting at a primitive whose port is declared unmapped, Gedae propagates this unmapped status through all zero-copy primitives. When a port that is marked unmapped is connected to a non-zero copy primitive whose port is not unmapped, then Gedae automatically inserts a primitive to move data between the unmapped and mapped ports.

For example, consider the following graph. In this graph the `mzt_vzt` box is a zero-copy box that is connected at a higher level to unmapped memory so its memory ports are unmapped. It is connected to the `vz_range` processing graph that consists of a `vz_multV` followed by a `vz_fft`. These primitives modify the data and their ports are therefore mapped. Following the `vz_range` is a `vzt_mzt` box whose ports are again unmapped. When Gedae schedules the execution of these primitives it must insert `getu` primitives between the `mzt_vzt` box and the `vz_multV` box. (It must insert two primitives since the split complex data is really two data streams.) Following the `vz_fft` Gedae schedules two `putu` primitives to move the data between the mapped `vz_fft` memory and the unmapped `vzt_mzt` input pointer.



We see the getu and putu primitives inserted into the processing in the following Trace Table:



The getu and putu primitives are blocking. That is, the primitives start a DMA from unmapped to mapped memory and wait for the DMA to complete before allowing the

processing of the data to continue. Gedae allows the user to specify using a double buffering scheme to avoid waiting for the DMA's to complete until after one cycle of the schedule has executed. Double buffering allows processing to be done in parallel with IO and improves performance.


A user can enable double buffering using the Group Control Dialog Multi-Buffer Table. Gedae detects which subschedules can benefit from multibuffering and lists them by subschedule number in the Multibuffering tool. The user can expand any subschedule to see what primitives are contained in that subschedule. The user can turn on Multibuffering on individual subschedules by toggling the MB field. The user can turn on Multibuffering on all subschedules by selecting Edit->Set All MB Entries and setting the entries to the value "1".

When Multibuffering is enabled the subschedule is split into as many as three different subschedules that have the suffixes get, exec and put. The get subschedule is responsible for kicking off the DMAs to fetch data from unmapped memory, the exec subschedule is responsible for processing data and the put subschedule is responsible for kicking of DMAs to write data back to unmapped memory. Wait primitives are scheduled at appropriate places to wait for DMAs to complete but only after a full cycle of the schedule processing is done.


Name	MB
1	■
mzt_par_range	
[7]mzt_range	
mzt_vzt	
mzt_vzt	
vz_range	
vz_fft	
vz_fft	
vz_multV	
vz_multV	
vzt_mzt	
vzt_mzt	
2	■
3	■
4	■
5	■
6	■
7	■
8	■
9	■
10	■
11	■
12	■
13	■
14	■
15	■
16	■
17	■
18	■
19	■
20	■

The Trace Table below shows the execution of a multibuffered subschedule. At the beginning of subscheduling, the get subschedule is executed twice. Two buffers are fetched during this time. The first buffer will be used by the first firing of the exec subschedule and the second buffer by the second firing of the exec subschedule. The exec subschedule will wait for a get buffer, but once in the steady state it will do this only after a full cycle of exec processing is complete. Thus, the input DMA is overlapped with one cycle of the processing. Similarly there are multiple output buffers. The put_nw kicks off a DMA from an output buffer but only waits for the DMA to complete after one full cycle of the processing when it will be necessary to use the buffer again.

The arrows in the diagram below show which the wait kernels that are associated with the get_nw and put_nw primitive executions.



Below we see that when the subscheduling of the input matrix completes on the last cycle a get is not executed because the buffer to be processed was already retrieved on the previous cycle. However, a wait is invisibly executed at 1 to implement the wait that is a part of the get schedule. After the last cycle, two wait kernels that were invisibly issued at 2 by the Gedae wait for the last two put schedule executions that do not have corresponding waits.



While the above Trace Tables illustrate how the multibuffering works, they do not show a great benefit in efficiency because in these examples the `vz_vmultV` and `vz_fft` are long compared to the `getu` and `putu`. The processing is CPU bound. When the processing times are shorter – as they are when running on the Cell/B.E.-- the processing becomes I/O bound, and the multibuffering becomes important and can greatly reduce the processing time.

Gedae automatically insert different primitives to move data between unmapped and mapped memory depending on whether the buffers are tiled or not and depending on if multibuffering is turned on or not. In addition, even if the memory on both sides of a connection is mapped but one side is tiled and the tile is embedded in a larger matrix and the other side of the connection is not tiled, then Gedae automatically inserts a box to move data from the tile to the non-tiled port. A summary of the different types of primitives that can be added in all of these cases is illustrated in the table below. If the Get/Put column is labeled `get`, then the Unmapped and Tiled columns apply to the source port of the connection requiring a translation primitive. If the column is labeled `put`, then the Unmapped and Tiled columns apply to the destination port of the connection.

Get/Put	Unmapped	Tiled	Multibuffer	Box Name
get	no	no	x	no function needed
get	no	yes	x	internal/mt_m


get	yes	no	no	internal/getu
get	yes	no	yes	internal/getu_nw
get	yes	yes	no	internal/mtu_m
get	yes	yes	yes	internal/mtu_m_nw
put	no	no	x	no function needed
put	no	yes	x	internal/m_mt
put	yes	no	no	internal/putu
put	yes	no	yes	internal/putu_nw
put	yes	yes	no	internal/m_mtu
put	yes	yes	yes	internal/m_mtu_nw

Note, a transfer port is not considered tile if the tile size only differs in the row dimension. That is, a matrix `out [256:512] [128:128]` connected to a matrix `in [256] [128]` does required a tiled transfer. In this case a `getu` or `getu_nw` transfer primitive is inserted if the out source is unmapped.

8 Priority Table

A schedule orders the execution of kernels. Scheduling, that is, the creation of schedules, happens during compilation. Several orderings may be possible. The user may wish to order the kernels in a specific way to handle external side effects, order sends and receives, etc. This ordering can be affected by the user through the setting of priorities. Because Gedae cannot create an illegal schedule, some priority settings may have no effect.

The default priority for each kernel is 0. Setting a priority to a positive number moves it up in the schedule, that is, it will potentially fire earlier. Setting a priority to a negative number moves it down in the schedule.




The screenshot shows a window titled "Group 2 Priority Table" with a menu bar containing "File", "Edit", "View", "Options", and "Help". The main content is a table with three columns: "Name", "Priority", and "Partition". The table is organized into two sections: "Schedule 1" and "[0]range_p".

Name	Priority	Partition
Schedule 1		
[0]azimuth_p		
delay	0	0
mx_adjoin	0	0
mx_trans	0	0
mx_vx	0	0
vx_fft	0	0
vx_ifft	0	0
vx_multVX	0	0
vx_mux	0	0
vx_mx	0	0
vx_subvec_1	0	0
vx_x	0	0
[0]range_p		
vx_cut	1 *	0
vx_fft	1	0
vx_multV	1	0
vx_zfill	1	0
x_vx	1	0

9 Memory Packing Control

The Static Memory Packer Pulldown Menu in the Group Control Dialog allows selecting between different memory packing algorithms. All memory packing is done during compilation, but larger applications may wish to use more lightweight algorithms to reduce compile time at the price of memory usage. The default is Fast Packer – a lightweight algorithm. Single Block Packer and Multi Block Packer provide progressively better packing but take longer to calculate the packing. No Packing is available to skip memory packing altogether.




10 Setting Dynamic Queue Properties

The Queue Table is used to display information and control the capacity of dynamic queues. The Queue Table is launched by pressing the Queue Table button in the Group Control. The table lists all the dynamic queues in the group. The Name shows the destination of the dynamic queue. The Capacity is shown in number of tokens, where Bytes is the storage size allocated to hold this capacity, that is, the capacity times the token size. The Memory Type shows which memory bank the queue is allocated in, and if multiple banks are available, allows for the mapping of the queue to memory. For example on the Cell/B.E. processor, the user may wish to map queues to huge TLB pages for efficiency.

The Src and Dest Policy provide information on when schedules fire according to the presence of tokens in the queue. The Src Policy specifies when the source schedule fires, and the Dest Policy specifies when the destination schedule fires. The possible policies are:

- cont – a controlling queue. The schedule will fire if any tokens or space are available, shrinking itself to handle the smallest availability on a controlling queue.
- req – a required queue. The queue requires the number of tokens dictated by the controlling queues before it will fire.
- n-req – a non-required queue. The schedule can fire even if no tokens are available on the queue and may, while running, determine that tokens are actually needed.



The screenshot shows a window titled "Group 1 Queue Table" with a menu bar (File, Edit, View, Options, Help) and a table of dynamic queues. The table has six columns: Name, Capacity, Bytes, Memory Type, Src Policy, and Dest Policy. The data is as follows:

Name	Capacity	Bytes	Memory Type	Src Policy	Dest Policy
Source3					
mz_repeat					
mf_repeat_1<in	1	4194304	default	req	cont
mf_repeat<in	1	4194304	default	req	cont

11 Setting Static Schedule Thread Properties

The Schedule Parameters dialog provides easy access to a list of schedules and information about the schedules, such as finding what primitives are in each schedule. It also allows for the setting of thread properties for the schedules. The table is opened by pressing the Schedule Parameters dialog in the Group Control. Each schedule acts like a thread on the target processors. If a partition has multiple schedules, then the runtime kernel is responsible for determining when to execute each schedule. The settings and data in this dialog can help describe the policy for running schedules and allow the user to set priorities, to set periods and to retry times for schedules.

The Name field is grouped by partition. Each partition can have multiple schedules mapped to it. Each schedule may have several subschedules. The Name column may also list Memory Segments, relating to memory partitions created in the Memory Partition Table.

Each schedule is listed with its size in bytes and its length in number of kernels. The following parameters can be set:

- **OV** – For BSPs that support overlays this column allows the user to select what parts of the application go into a separate overlay. If set for a partition then Reset methods are placed in their own overlay. If set for a schedule then the schedule is placed in an overlay. If set for a subschedule then the subschedule is placed in an overlay.
- **Priority** – aids the runtime kernel in choosing which schedule to run first. Schedules with larger priority (closest to positive infinity) will execute first, and schedules with lowest priority (closest to negative infinity) will execute last.
- **Period** – tells the runtime kernel the period between schedule firings. The default setting, relating to a blank entry in the column, is to follow dataflow policy, that is, the schedule should fire when data is available. A period can be entered in seconds or number of schedules.
 - **Seconds** – if in seconds, then the number of seconds must elapse between the start of successive execution of the schedule. This period is useful for emulating real-time data sources or for monitoring other external resources.
 - **Schedules** – if in schedules, then the given number of schedules must fire before this schedule fires again.
- **Retry** – tells the runtime kernel when to retry firing a schedule if there is an error condition such as a primitive calling `embSuspendRetry()`. The retry period can also be in seconds or schedules.
- **Memory Type** – where to allocate the data buffers for the schedule in memory.

Additionally, the Schedule Parameters dialog provides a set of Boolean flags to specify information about the schedule used by the runtime kernel, such as whether it uses shared memory, requires exclusive locks to access memory, and other runtime scheduling issues. A full list of these flags is available in the Help message for the dialog.

12 Launch Package Generation Control

A Launch Package is a directory containing executables that allow a single group to be executed independently from the development environment. A command program is also generated to control the loading, launching and execution of all the executables. There are three options for using this launch package:

- As a standalone, deliverable application
- As a parent application integrating with non-Gedae components through customization of the command program
- As a child function through use of the function interface to the command program.

Launch Package Information

Group Name:

Parameters

Type	Name	Synonym
float	Fc	<input type="text"/>
float	Fs	<input type="text"/>
float	demod<Fb0	<input type="text" value="Fb0"/>
float	e_channel<SNR	<input type="text" value="SNR"/>
float	demod.demod1<Adc	<input type="text" value="Adc"/>

Executables

- Create Schedules in Command Program
 - Create Target Executables as Arrays in Command Program
 - Create Unified Target Executable
- Create Schedules in Target Executables (No Host)

Launch Package

Directory:

Command Program:

Command Program Library:

Parameters and Queues

The Parameters and Queues visible to external software are listed in the dialog. The default names of these data are based on the hierarchy of the flow graph. Shorter names can be given by specifying Synonyms. The Parameters are all parameters that can be changed at runtime; the compiler aggressively precomputes parameters to avoid runtime recalculation. The Queues are the boundaries between groups created by the boxes in the embeddable/stream/host directory.

Executables

The executable creation can also be customized to best suit the target hardware. Note: target hardware provides a target-specific value of these settings. The settings are

- Create Schedules in Command Program – The schedule information is contained in the command program and sent to the target processors at start up.
 - Create Target Executables As Arrays in Command Program – This option code generates binary arrays representing target executables into the command program. The option may not be available on all target processors.
 - Create Unified Target Executable – This option creates one executable containing all partitions and all kernels of the graph. This option reduces the storage requirements as only one executable is created and can be used to support targets that require SPMD (Single Program Multiple Data).
- Create Schedules in Target Executables (No Host) – Target executables are completely self-contained and start up without host intervention. Note: running without host intervention disables useful debugging features such as trace collection.

Launch Package

The command program can be customized using the Command Program Interface. The directory to store the launch package, any customizations to the command program C source file, and libraries or object files to link with the command program can be placed in the Command Program section of the dialog. Each of these entries is a path to the corresponding directory or file(s).